



LHS Crane Scales

LHS hanging scales offer shipping and production operations a strong and safe solution for weighing heavy loads. Ruggedly constructed to perform dependably in industrial settings, the LHS boasts cast aluminum magnesium indicator housing, chrome-plated steel hook, safety catch and oversized swivel shackle and bolt. The hook and shackle rotate, giving complete flexibility. A standard remote control allows safe and simple operation of the scales. Readings are shown on a bright-red LED display, making them visible in any lighting conditions, including outdoors. The hold function retains the reading on the display after the weight is removed from the scale, allowing time for the operator to record the value. Other practical features include a colour-coded, sealed keypad; external calibration; and full-range tare. An internal rechargeable battery is easily accessible for quick replacement.



LHS Crane Scales

Features

- Bright LED display for easy viewing in most environments
- Rotating hook allows flexible handling of bulky or oversized objects
- Lightweight design simplifies transport and portability
- Remote control allows safe, hands-free operation
- Rugged construction stands up to industrial use
- External calibration allows for verification and adjustment with weights
- Hold function freezes the displayed weight, allowing time to lapse without losing the result
- Zero-tracking feature ensures display returns to zero reading
- Programmable auto power-off to save energy

Applications

- Weighing



Crane remote included

Model	LHS 500	LHS 1500	LHS 2000
Capacity	500kg	1500kg	2000kg
Readability	0.1kg	0.2kg	0.5kg
Repeatability (S.D.)	100g	200g	500g
Linearity (+/-)	200g	400g	1000g
Ultimate Overload Limit	750kg	2250kg	3000kg
Weighing Units	kg, lb, N		
Stabilisation Time (sec)	2		
Calibration	External calibration		
Display	LED with 25mm-high digits		
Power Supply	AC adapter / Internal rechargeable battery		
Operating Temperature	5° to 40°C		
Housing	Die cast aluminum		
Overall Dim.	195x130x450mm		
Net Weight	4.80kg		
Overload Limit	Adam Equipment Co Ltd, its directors, staff, owners and affiliated companies and organisations cannot be held liable for any resulting damage or injury sustained as a result of the machines being used in excess of their capacities and ultimate overload limits.		

With more than forty years of experience in the production of balances and scales, professionals worldwide rely on Adam for feature-rich, quality products with best-in-class value - The right balance of speed, performance and value.

Supplied by: