



With rugged construction to endure demanding washdown environments, PT stainless steel platform scales provide the ultimate in durability for a variety of commercial, industrial and mining applications. PT stainless steel platforms offer a capacity up to 3kg and a readability of up to 0.5kg, and are available in three square platform sizes: 1000mm and 1500mm. Ideal for weighing food products, chemicals, pharmaceuticals or mining materials, the PT stainless steel platform features an IP66-rated load cell and stainless steel junction box, sealed for protection against water and dust. Easy to clean, the grade 304 stainless steel plate can tolerate frequent washing, while the sleek brushed surface helps prevent the accumulation of food and dirt particles. The PT stainless steel scale is supported by a reinforced frame beneath the platform, allowing the scale to accommodate substantial loads. Offering solid, dependable stability, PT stainless steel's heavy-duty rubber feet are adjustable to compensate for uneven weighing surfaces. Optional ramps are tailor-made to fit the exact size of each platform. PT stainless steel platform can be paired with the AE 402 indicator to provide the features and functions needed for any demanding washdown weighing task.

## Compatible Indicators



AE 402 Indicator

## IP66-rated platform ideal for washdown environments



## Features

- Rugged stainless steel housing for ultimate durability
- Approximately three-meter/10-foot shielded cable
- Can be used with any Adam indicators
- Heavy-duty rubber feet ensure stability of unit
- IP66-rated for protection against water and dust

## Applications

- Weighing
- Parts counting
- Checkweighing
- Dynamic / animal weighing

### About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	PT 110S	PT 310S	PT 115S	PT 315S	PT 110S [AE402]	PT 310S [AE402]	PT 115S [AE402]	PT 315S [AE402]
<b>Capacity</b>	1000kg	3000kg	1000kg	3000kg	1000kg	3000kg	1000kg	3000kg
<b>Readability</b>	0.2kg	0.5kg	0.2kg	0.5kg	0.2kg	0.5kg	0.2kg	0.5kg
<b>Repeatability (S.D.)</b>	0.2kg	0.5kg	0.2kg	0.5kg	0.2kg	0.5kg	0.2kg	0.5kg
<b>Linearity (+/-)</b>	0.4kg	1kg	0.4kg	1kg	0.4kg	1kg	0.4kg	1kg
<b>Excitation Voltage</b>	5 - 10 VAC / DC							
<b>Loadcells</b>	4							
<b>Pan Size</b>	1000x1000mm		1500x1500mm		1000x1000mm		1500x1500mm	
<b>Weighing Units</b>	N/A				g, kg, lb, lb:oz, oz, N			
<b>Stabilisation Time (sec)</b>	2							
<b>Interface</b>	N/A				RS-232			
<b>Calibration</b>	N/A				External calibration			
<b>Display</b>	N/A				Backlit LCD with 0mm -high digits			
<b>Power Supply</b>	N/A				12VDC 50/60Hz 800mA adapter / Internal rechargeable battery			
<b>Operating Temperature</b>	-10° to 40°C							
<b>Housing</b>	Stainless steel							
<b>Cable Length</b>	3M							
<b>Overall Dim.</b>	1000x1000x110mm (wxdxh)		1500x1500x110mm (wxdxh)		1000x1000x110mm (wxdxh)		1500x1500x110mm (wxdxh)	
<b>Net Weight</b>	62kg		111kg		62kg		63.4kg	
							111kg	
							113.4kg	

## Accessories

Item number	Description
700660289.....	Calibration certificate
2050013351.....	Indicator stand

Supplied by